












NuCore Extreme 12mm Technical Information

Usage	Result
	
	
	
	
	
	
	
	
	
	
	
	

Installation Methods	
	
	
	
	

*Subject to compatible subfloor and correct installation (Refer Installation Instructions)

Test Information & Others	
	
	
	
	
	
	
	
	
	
	
	
	
	

Installation & Warranty

All NuCore floors must be installed by a competent approved installer who will have the necessary skills and take individual site circumstances into account. NuCore warranty will only apply to floors which have been installed according to the NuCore installation instructions available in each box of NuCore and also on the TerraMater website - terramaterfloors.com.au

Please note this technical sheet was written by TerraMater Floors Pty Ltd. All the information is specified correctly while writing and publication of the sheet. The company reserves the right to change the specifications of the this product at any time without prior notice to third parties.