


# WildOak BY TERRA MATER

WildOak timber flooring by Terra Mater is synonymous with quality innovation and designer appeal.

WildOak emerges from the sustainable oak plantations of Europe, guaranteeing sophistication and quality.



01

### WildOak - LinWood

1860 × 190 × 12mm (T&G)

7

02

### WildOak - LakeWood


900 × 190 × 14mm (5G)	13
Herringbone 888 × 148 × 14mm (T&G)	15

03

### WildOak - Origins

900 × 190 × 14mm (T&G)	23
2200 × 220 × 14mm (T&G)	25
2200 × 240 × 15mm (T&G) <b>DISCONTINUED</b>	27

WildOak | 1



### LinWood

**Entry Range (Engineered Oak)** 

Simple, stylish and affordabe range for any interior space.

### LakeWood

Life Style Range (Engineered Oak)

Our widest range of engineered oak flooring.

# Origins

Premium Range (French Engineered Oak)

Your sophisticated choice of unique luxury French oaks.

### LinWood

LinWood is the way to have a real timber floor for less financial outlay and still get a 20+ year lifespan. LinWood's top layer (lamallea) is a high grade European Oak made from a species of oak which will provide high durability. The result? A floor that is more economical and uses less natural resources while maintaining long term performance. That's what you get when using the best materials available.


10 modern colours lend themselves to any style of home or décor. LinWood's timber surface is graded specifically to achieve a classical and clean look.



20year

Domestic Wear
Warranty


Lifetime Structural Warranty



# LinWood (1860 x 190 x 12mm)

Tongue UV Lacquer

4 Sided Micro Bevel





### LakeWood

Inspired by our passion to produce beautiful flooring, our ranges have been sourced from managed forests throughout Australia, Southeast Asia and Europe.

Terra Mater's mission arises from our passion for wood and timber - to bring our customers superior quality flooring, from the forest floor and the environment.





Lifetime Structural Warranty



#### The best materials available

Our premium grade European Oak comes from managed forests and is milled to meet our stringent grading requirements. Our factory uses the latest German machinery to produce precision engineered flooring that will stand the test of time.

LakeWood Oak prides itself on its 9 coats of German Klumpp coating leaving you with an extreme matte finish. Our special invisible UV lacquer makes you feel like you are walking directly on the natural wood, while still possessing the durability and cleanability of a highly polished floor.

The glue used to bond the European Oak to the Hardwood core is supplied by Swedish producer Dynea for superior bond strength, to not only comply but, to exceed stringent emissions regulations for off gassing of VOCs (volatile organic compounds) and is fully verified by Australian test certification to back our quality and eco friendly products.

Terra Mater production and laboratory quality assurance teams are on-site 24 hours a day at our factories where they tightly control all production runs. Strict implementation of stringent standards and fine tolerances during all phases of production ensure that we maintain consistency of quality standards across all Terra Mater products.



# LakeWood (1900 x 190 x 14mm)







Micro Bevel









# LakeWood Herringbone (888 x 148 x 14mm)







Dove Grey

Pearl Grey

Onyx Pearl

Magnolia





French Grey







& Groove





# Origins

The evolution and culmination of rich centuries old wood and hand crafting mastery, WildOak Origins takes you from the cradle of French Oak flooring to the dynamic, timeless look and performance of technological prowess. Origins takes old world strength and beauty and applies the latest manufacturing, colouring and texturing techniques to deliver an uncompromising floor. Origins is not just a floor - it is a deep statement about our passion for fashion and décor.

Our love of nature and enhancing that inherent strength and beauty for you.




20year

Domestic Wear

Warranty

Lifetime Structural Warranty






# There are a few distinct qualities that set French Oak apart from oak sourced out of Eastern Europe, China and America.

One inherent difference is that the tannin content is much higher in French Oak than all other oak. Tannin is a substance made from the polyphenolic compounds that are found in the wood. The high content of tannin means that our reactive stain technology is far more effective in achieving a subtle reaction with the wood resulting in different tones and colours that cannot be found in other oak.

### French Oak Superiority over Eastern European Oak, American White Oak and Chinese Honey Oak:

- Higher tannin content for reactive stains fuming and ageing.
- Tighter grain structure producing a more dense timber suitable for flooring.
- More stable raw material suitable for Australia's harsh climate.





# **Origins** 190mm (1900 x 190 x 14mm)







Marais

Urchin Grey

Chanson







Malay Grey

Arava

Spice









4 Sided Tongue UV Lacquer Micro Bevel & Groove 10% Matte



Arava | 1905

# **Origins** 220mm (2200 x 220 x 14mm)





Colac

Tobacco

Astoria







Lunar Grey

Grey Ember









4 Sided Tongue Micro Bevel & Groove



Origins 240mm (2200 x 247 x 15 mm)



Lyon

Hand Brushed

Semi Fumed



Tongue 4 side & Groove micro bevel

8% Matte UV Lacquer French Oak

Lacquer 8%

Nice


Triple Smoked

White Wash UV Lacquer 8%

Smoked

Reactive Stain

UV Lacquer 8%



### **Warranties & Test Reports**

A superior floor guaranteed with a 20-year wear warranty

Our superior quality flooring meets all international Quality Control Standards up to and including ISO 9239-1:2002. Our Lifetime Structural Warranty, 20 Year Domestic Wear Warranty and 5 Year Commercial Wear Warranty ensure that you will enjoy your floor for many years to come.

When you choose WildOak, you can enjoy peace of mind knowing that your floor has undergone rigorous testing to ensure it's quality and safety. WildOak has proven test certificates that cover fire, dry slip, wet slip and emission testing. To download these certificates, head to our website.

www.terramaterfloors.com.au





Lifetime Structural Warranty



### Cleaning and Maintenance Guide

#### **Preventative Maintenance**

It is only natural that laminate floors will show signs of wear over time. You can expect years of beauty from your floor by observing a few precautions and maintaining regular cleaning and maintanance routines.

- Keep dirt, sand, grit and water off the floor by placing outside mats in front of all entrances to your home.
- Sweep or vacuum regularly to rid the floor of dust and grit that can scratch the finish.
- Remove shoes with spiked or damaged heels before walking on the floor to prevent scratches and dents.
- Keep pets' claws trimmed, paws cleaned and free of dirt or soil.
- Always apply felt pads under any furniture or chair legs to prevent scratches and to ease movement. Keep pads clean at all times and regularly check and replace as necessary.
- Protect the floor when moving heavy furniture or large appliances. Place on mat and slide smoothly over floor.
- Never flood or wet mop floor with water or any other liquid products. Severe damage may occur that voids the warranty.
- Wipe up spills immediately with damp cloth.
- Exposure to sunlight with its UV rays accelerates oxidation and aging of materials.
   This may change the colour of the floor.
   Periodically rearrange the furniture to allow the floor to age evenly.

#### **Cleaning After Installation**

- Remove all loose debris from the floor using a vacuum, brush or dust mop (if using a vacuum, please check the manufacturer's guidelines to make sure it's suitable for WildOak.
- 2. Ensure that all dry adhesive or wax is removed from the surface.
- 3. Damp mop with a pH neutral detergent.

#### **Routine Maintenance**

The cleaning and maintenance regime, whether for commercial or residential homes is simple and can be carried out by hand or using mechanical cleaning apparatus.

Spills and tracked-in dirt should be wiped up immediately.

- Periodically, as necessary, thoroughly clean the floor with a good quality spray mop and with a ph neutral cleaner. DO NOT allow excess cleaner to remain on the floor's surface. Excess liquid may damage both the surface and core of your laminate floor.
- Vacuum, sweep or mop to remove all dust and loose debris (if using a vacuum, please check the manufacturer's guidelines to make sure it's suitable for WildOak).
- Stubborn stains can be removed by spot cleaning with concentrated ph neutral detergent.
- 4. Never use any of the following products (or similar in nature) on your floor: ammoniabased cleaners, acrylic finishes, wax-based products, bleach, polishes, oil soap, abrasive cleaning soaps, or acidic materials such as vinegar. Many of these products pit or etch the finish of your flooring or prevent the proper use of recommended maintenance materials.
- 5. It must be noted separately that Evaporative cooling will severely increase the moisture levels within the home. Again the humidity level of the environment must be kept below 60%, a figure very difficult to achieve with this type of cooling. Damage to flooring is very common with this type of cooling and generally will not be covered by warranty.
- 5. The OPTIMAL HUMIDITY for WildOak Flooring is between 40% 60%. If humidity drops below 40% and above 60% over an extended period please either humidify or dehumidify the home or environment where the floor is installed. Maintaining a consistent and correct in home environment is very important so the flooring will not suffer any potential structural damage or dimensional changes, such as cupping, shrinkage, checking or gapping. It must also be noted that creaking or squeaking can also be caused by dimensional changes to the product caused by poor humidity control in the environment.
- Use interior and exterior doormats at all entrances to collect dirt and moisture and prevent it from being tracked onto the floor.
- 8. Area rugs are recommended in front of kitchen sinks, at all pivot points within high

- traffic areas. Do not use rugs with solid rubber or vinyl backings. The rugs must be made of a breathable material to prevent moisture entrapment.
- Never clean or wet mop with water, it may permanently damage the floor.
- 10. Cut hair is very coarse and will abrade the surface of the flooring.
- 11. Keep animal nails trimmed to minimise finish scratches
- Do not damage your floor with shoes having heel taps or sharp objects protruding from the sole such as rocks, nails or gravel.
- 13. Avoid walking on wood floors with spike or stiletto heeled shoes. Spike or stiletto high heels must be properly maintained to prevent damage from the steel heel support.
- 14. Do not roll or slide heavy objects directly upon the floor. When moving appliances or heavy furniture, consider laying a solid protective covering on your floor and gently "walk" the item across it. Carpet or cardboard is not adequate to prevent surface compression scratches.
- Use furniture leg protector pads under all furniture and make certain to keep them clean and well maintained.
- The flooring should be protected with non rubber matting from damage by casters and wheels on furniture and chairs.
- Protect your floor from direct sunlight. Use curtains and UV resistant film on large glass doors and windows. Colour shade variation can occur if the floor is exposed to direct sunlight.
- 18. The use of any kind of steam mop is strictly prohibited. The use of a steam mop will cause irreparable harm to your floor and void your warranty.
- 19. Radiant heat from fire places or heater should be avoided. Damage can occur.

IMPORTANT: Heavy objects such bookcases, billiard tables, kitchen units, that exceed 200kg/object area or if the load is greater than 30kg/cm2 should not be placed on a floating system. Damage can occur due to incorrect expansion and lack of correct raft movement.

We do not recommend adhesive tape is applied to any of our flooring products.



All warranties and product certificates please refer to website under downloads. www.terramaterfloors.com.au



WildOak | 29



**Terra Mater - Melbourne** 23-27 Rodeo Drive Dandenong South VIC 3175 Australia 1300 671 777

sales@terramaterfloors.com.au

Terra Mater - Sydney 1 Lennox Drive Wetherill Park NSW 2164 Australia 1300 671 777

sydneysales@terramaterfloors.com.au

#### Disclaimer

Product images may vary in colour due to possible printing process variations. Images should not seek to duplicate the exact visual appearance, but serve merely as a guide or point of reference. Actual samples should be inspected to confirm texture and colour before making a purchase decision.